## **CONGRATULATIONS!**

You are the proud owner of a Miller Lite Cantenna. No more sketchy websites, no more paying for cable, and no more missing out on Miller Time with friends.

- **STEP 1** Gently unbox your new Cantenna. It may be easiest to remove from the bottom of the box if your hand cannot fit comfortably in the top of the box.
- **STEP 2** Open the cover at the base of your Cantenna to uncoil the coaxial cable and place near your TV.
- **STEP 3** Turn off your TV.
- **STEP 4** Connect the coaxial cable to the input port of your Cantenna. Locate the input port on the back of your TV, then plug in the cable and, if possible, tighten the connector.
- **STEP 5** This may be a good moment to grab a cold Miller Lite from the fridge. Okay, back to the Cantenna.
- **STEP 6** Turn on your TV. Using your remote, set your input to 'TV'.
- **STEP 7** Navigate your settings and select 'scan for channels'. You may need to consult your TV manual for this.
- **STEP 8** As you have a directional Cantenna, you'll want to point it toward the nearest broadcast station. You may also need to move items in your home out of the way of the antenna's connection path. Adjust as needed.
- **STEP 9** Enjoy your new Cantenna by watching a game with friends.

STEP 10 IT'S Miller TIME

\* Station availability is subject to your specific location & location of Cantenna within the home.

